


3-SIDED MOBILE KIT




kit contents

- (2) three-pronged mobile centers
- (6) pieces of two-sided permanent foam tape
- (1) ceiling hook with string

step 1


Using the double-sided foam tape, affix the panels of your sign together, as shown.



step 2

Push the tips of the three-pronged centers through the corresponded holes in your sign.

With a slight pinch, the arrow-head shaped tips will pass easily through 1/4" holes. Release the pinch and the arrow-heads expand to hold tightly in the holes



step 3

On the top three-pronged center, gently bend the hanging point into an upright position.

Pass the barbed-end of the hanging string through the hanging hole on the three-pronged center.

Deploy a desired length of string from the ceiling hook (note: cinch the top of the deployed string in the ceiling hook's notch — this will keep unused string from being deployed)

Hang the mobile by attaching the ceiling hook to a ceiling grid or other suitable attachment point.